





Setting the Time, Day and Date

Setting the Time, Day and Date:



Press  and the cursor is on “**REMOVE CAR FROM LANE**”.


Press  until the cursor moves to “**SET PARAMETERS**”.


Press  and enter the **6** Digit Access Code. Default Code is **000000**. (Contact Delphi Display Systems Customer Care Center at 800-456-0060, EXT.1, Option 2 if code doesn't work). The cursor is now on “**ACCESS CODES**”.



Press  until the cursor moves to “**TIME/STORE HOURS**”.


Press  and the cursor is now at the **HOUR** in the upper left corner of the display.


Press  or  to increase or decrease the **HOUR** accordingly. NOTE: AM/PM is adjusted by the HOUR.


Press  until exited back to the Main Screen if no further adjustments are needed, **OR** follow the steps below to adjust Minutes, Month and/or Date. Adjusting Date will automatically adjust Day of Week.


Press  to move to the **MINUTES**


Press  or  to increase or decrease the **MINUTES** accordingly.

Press  to move to the **MONTH**

Press  until the correct **MONTH** is set.

Press  to move to the **DATE**.

Press  until the correct DATE is set. Note: Adjusting the Date will automatically adjust the Day of Week.

Press  until exited back to the Main Screen.

10:21	AM	TUE	OCT	10
WEEK: 2			YEAR: 2000	
1ST	DAY	OF WEEK:	MON	
		OPEN	CLOSE	
SUN	6:00AM	-	12:00AM	
MON	6:00AM	-	12:00AM	
TUE	6:00AM	-	12:00AM	
WED	6:00AM	-	12:00AM	
THU	6:00AM	-	12:00AM	
FRI	6:00AM	-	12:00AM	
SAT	6:00AM	-	12:00AM	
<ARROWS>		TO MOVE		
<+ OR ->		TO SET T&D		
<MAIN MENU>		TO EXIT		